



The better alternative for sealing rubber cement.

V-Matte is a non-toxic, water-based matte sealant for use on all rubber cement based paints. It will seal the paint, taking away all "stickiness" and leave it with a matte finish that is ready for use, blending with makeup or repainting at any time.

SHAKE WELL BEFORE USE. The solids that help with the sealing properties of V-Matte will settle, leaving a thick white build-up on the bottom of the bottle. Shaking will remix the solids. It is for this reason that the V-Matte should be force dried after it is applied. If allowed to dry on its own the solids may settle and puddle into sculpted detail. When dry it will appear white. Force drying avoids this because it dries the V-Matte quickly and keeps the solids in suspension. A blow dryer works best.

Application by spraying

Using an airbrush works better than a large spray gun. The reason being that the V-Matte can dry on the larger needle and opening of a spray gun and clog quickly. Also, unless adjusted, a spray gun will use more of the V-Matte than is necessary. This being said, a spray gun works quite well for sealing suits and other large pieces. For prosthetics, an airbrush is preferred as it gives better control of the application. A bottle-fed airbrush works quite well as you don't have to keep refilling as often as if you used a top- or gravity-fed airbrush. If you're using a spray gun or an airbrush (especially a bottle-fed one) and you let it sit, unused for a while, the V-Matte can build up on the inside of the siphon tube and inside the airbrush around the needle and on the needle tip. It is recommended that you spray out some V-Matte for a couple of seconds to clear the build-up out of the airbrush. If this isn't done the build up may spray onto the painted surface and leave a white residue. Being a water-based material it will tend to dry on the tip of the needle during normal use. Remove the dried bits as needed.

EVERYTHING EXCEPT SHOES LTD.
WELLINGTON, NEW ZEALAND EES.LTD@USA.NET



The better alternative for sealing rubber cement.

Application by brush

Using a brush to apply V-Matte works well for items that do not require as much care being taken with them, such as masks or any other items that do not have blending edges or other delicate areas or items that are large, such as suits.

Apply the following to both methods of application

The V-Matte can be applied in either a light or heavy layer. If the piece being sealed has a smoother texture try applying the V-Matte lightly and then force dry. If the piece has heavy texture, try a heavier application. This will help the V-Matte get into all the sculpted recesses. When force drying keep a paper towel handy to blot up any drips or puddles that may occur. Do not soak up too much of the V-Matte or you may not get a good coat and it may still be sticky when dry. You can apply a second coat if needed without any adverse affects.

Cleanup

Use water to clean out the spray gun or airbrush. DO NOT use alcohol to clean out the V-Matte. Alcohol will turn the V-Matte into a thick, sticky sludge. Once all the V-Matte is removed you can run alcohol through to remove the water.

To clean off of skin use warm, soapy water. The use of alcohol will, again, turn it into a slimy mess. When dry it can be peeled off of the skin.

Warning

When spraying V-Matte take all precautions that you would normally take (ie good ventilation, respirator, etc).

EVERYTHING EXCEPT SHOES LTD.
WELLINGTON, NEW ZEALAND EES.LTD@USA.NET